

LIMIT ADJUSTING

Instructions

Note: Motors come pre-programmed with short limits.

To change lower limit, send the motor to its current lower limit by pressing the down arrow.

Press both the up and down button at the same time until the motor jogs. Adjust to your desired lower limit and press the “my” button until the motor jogs. This saves your lower limit.

To change the upper limit, send the motor to its current upper limit. Press both the up and down buttons at the same time until the motor jogs.

Adjust fabric to your desired upper limit position and press the “my” button until the motor jogs.

This saves your upper limit.

Send the shade to both the upper and lower limits. The shade should stop at the programmed limit settings.

You're done!