

PREMIUM MOTOR

Installation Instructions

Insert premium motor where the motor wire is exiting straight out the back at eye level. This will help keep the wire out of the way during programming.

PROGRAMMING “HANDING” *for fabric rolling off back of tube*

(When programming multiple shades with a multi-channel remote, always ensure that you have selected the proper channel and that all other motors that are not yet programmed are not powered up)

- 1) Connect power to motor. Once power is connected the motor will beep for a full second
(Note: once power is connected you have 10 seconds to start the programming)
- 2) Press the P2 button twice on the back of the remote. The motor will beep each time you press the button
- 3) Program proper handing
 - a) For RIGHT handed operation press DOWN button
 - b) For LEFT handed operation press UP button

Once handing is selected the motor will beep repeatedly to confirm programming is complete. The motor is now programmed with “handing”, you may disconnect power or leave it powered up to continue programming other motors if needed. Once again always remember to select proper channel if there are multiple motors to be programmed.

SETTING LIMITS

Lower Limit: (Shade should be hanging down approx. 1' from top)

- 1) Insert the Green limit tool supplied into the hole with arrow pointing UP
- 2) Press the DOWN button to roll the shade down, the shade will roll down a few feet and stop on its own
- 3) Turn the limit tool COUNTER CLOCKWISE to make the shade inch down to your desired lower limit

(NOTE: If shade rolls down too far, simply turn the limit tool CLOCKWISE a few turns, press the UP button to roll the shade up about a foot and press the STOP button. Next, press the DOWN button to roll the shade back down and the shade will stop short of where it did before. Repeat Step 3 to reach desired lower limit)

PREMIUM MOTOR

Installation Instructions

SETTING LIMITS *cont.*

Upper Limit: (Shade should be at its previously set Lower Limit)

- 1) Insert Green limit tool supplied into the hole with arrow pointing DOWN
- 2) Turn the limit tool CLOCKWISE 10 times
(NOTE: During Step 3 be ready to stop the shade in case the shade doesn't stop at the desired upper limit. If you have to stop the shade before it reaches the top, roll the shade back down a few feet and start back at previous step)
- 3) Press the UP button to roll the shade up. The shade will roll up and stop.
- 4) Once the shade stops turn the limit tool COUNTER CLOCKWISE to make the shade inch up to your desired upper limit

If at any time a motor is programmed with the wrong "Handing" or to the wrong channel, a **POWER CUT** will need to be performed. Performing a power cut will erase the motor and make it fresh and ready to reprogram.

POWER CUT

- 1) Press P2 button once, motor will beep
- 2) Press the STOP button once, motor will beep
- 3) Press the P2 button once, motor will beep repeatedly
- 4) Disconnect power

At this point, when the motor is powered up again it will be clean and ready to reprogram.

ASSIGNING MOTOR TO ADDITIONAL CHANNELS & REMOTES

Assigning a motor to another channel on remote

- 1) Select the motor you want to group on the remote
- 2) Press the P2 button twice
- 3) Select the desired channel you want to group on the remote
- 4) Press the P2 button once

Assigning a motor to additional remotes

- 1) Select the motor you want to add to additional remote
- 2) Press the P2 button twice
- 3) Select the remote you want to add on proper channel
- 4) Press the P2 button once